



# ModBus-RTU

Description of the protocol

Version: 3.0

18. February 2013



**Rawet**  
**Studio**

---

Rawet Ltd.

Čapkova 22

678 01, Blansko

515 416 942

<http://www.rawet.cz>

## 1. Table of contents

1. Table of contents.....	2
2. Description of functions .....	2
3. Functions 03 <sub>H</sub> a 04 <sub>H</sub> .....	3
4. Function 06 <sub>H</sub> .....	4
5. Function 08 <sub>H</sub> .....	4
6. Function 11 <sub>H</sub> .....	5
7. Error table.....	6
8. EEPROM map.....	6
9. Table 1 - Meaning of bits in the configuration word.....	7
10. Table 2 - Meaning of bits in the communication word .....	8

## 2. Description of functions

Communication with the transmitter is on the principle of MASTER - SLAVE.

Protocol MODBUS has the following structure:

<toff> <slave address> <function> <data> <CRC> <toff>

description parts of the protocol		
part of the protocol	meaning	number of bits
<toff>	delay more than character	
<slave address>	address from the range <1 ... 247>	8 bits
<function>	code number of the function	8 bits
<data>	meaning is given by the description of individual parts	N * 8 bits
<CRC>	checksum	16 bits

The command is represented by a tuple eight-bit data. If during the transmission is delay greater than time corresponding to dispatch 4 characters at a given baud rate, command receive is interrupted and decodes. First, it checks the CRC. If the converter gets incomprehensible data does not match. If the converter gets data with your address, but which contain a syntax error, responds with an error message. ([see error table](#)).

If the unit is correctly received command, it responds with the same answer as the query structure after a period longer than toff.

func.nr.	meaning	data command	data response
03 <sub>H</sub>	<a href="#">reading 16b of data</a>	16b - address reading register	8b – number of bytes on response
04 <sub>H</sub>		16b – number of reading registers	2*N bytes - data from registers
06 <sub>H</sub>	<a href="#">write 16b of data to the memory</a>	16b – address of write 16b – value data write	16b – address of write 16b - value data write
08 <sub>H</sub>	<a href="#">converter reset</a>	0001 <sub>H</sub> FF00 <sub>H</sub>	0001 <sub>H</sub> FF00 <sub>H</sub>
11 <sub>H</sub>	<a href="#">Report Slave ID</a>	nothing	8b - number of bytes on response (always 02 <sub>H</sub> ) MSB – type of converter LSB – SW version

### 3. Functions 03<sub>H</sub> a 04<sub>H</sub>

Functions 03<sub>H</sub> a 04<sub>H</sub> are the same. They are used for reading value of 16b register from the specified address.

The command structure is as follows:

<converter address> <03 or 04> <register address> <number of registers> <CRC>

Meaning of parameters	
part of the protocol	meaning
converter address	8b value from the range <1 .. 247>
register address	16b address the first reading address
number of registers	16b number of consecutive read registers acceptable values are only 0001 <sub>H</sub> , 0002 <sub>H</sub> a 0004 <sub>H</sub>
CRC	checksum

Significance of converter memory is shown in the table memory.

Answer a properly specified command is:

<converter address> <03 or 04> <2\*N> <N\*16b data values of consecutive registers > <CRC>

In the event of an error in the command is coming error message ([see error table](#)) or converter does not respond at all.

example		
description	command example	response example
Reading input value 32b	01 04 0003 0002 81CB <sub>H</sub>	01 04 04 FFFF FFCD 7BC5 <sub>H</sub> (-0,51 °C)
Reading 2*input value 2*32b	01 04 0001 0004 A009 <sub>H</sub>	01 04 08 0000 0280 FFFF FFCD A470 <sub>H</sub> (+6,40 a -0,51 °C)

## 4. Function 06<sub>H</sub>

Function 06<sub>H</sub> is used for write data value to the specified memory of the converter.

The command structure is as follows:

<converter address> <06> <register address> <data value> <CRC>

Meaning of parameters	
part of the protocol	meaning
converter address	8b value from the range <1 .. 247>
register address	16b address the first reading address
data value	16b value of data which you can write to the specified memory
CRC	checksum

Significance of converter memory is shown in the table memory.

Answer a properly specified command is:

<converter address> <06> <address of register> <16b data values> <CRC>

In the event of an error in the command is coming error message ([see error table](#)) or converter does not respond at all.

example		
description	command example	response example
write 16b value	01 06 1032 0C02 A804 <sub>H</sub>	01 06 1032 0C02 A804 <sub>H</sub>

Note: Values written to memory locations specifying the device configuration to take effect after a reset (see function 08h).

## 5. Function 08<sub>H</sub>

Function 08<sub>H</sub> will do SW reset of the converter.

The command structure is as follows:

<converter address> <08> <0001FF00<sub>H</sub>> <CRC>

Meaning of parameters	
part of the protocol	meaning
converter address	8b value from the range <1 .. 247>
0001FF00 <sub>H</sub>	fixed constant
CRC	checksum

Answer a properly specified command is the same as command.

In the event of an error in the command is coming error message ([see error table](#)) or converter does not respond at all.

Note: The Reset command is necessary to do always when change the transmitter configuration or after the change in the configuration of communication.

## 6. Function 11<sub>H</sub>

Function 11<sub>H</sub> serves to identify the transmitter and its included software.

The command structure is as follows:

<converter address> <11> <CRC>

Meaning of parameters	
part of the protocol	meaning
converter address	8b value from the range <1 .. 247>
CRC	checksum

Answer a properly specified command is:

<converter address> <11><number><type><SW> <CRC>

Meaning of parameters in the answer	
part of the protocol	meaning
converter address	8b value from the range <1 .. 247>
register address	16b address the first reading address
number	8b number of bytes on answer-are only 02 <sub>H</sub>
type	70 <sub>H</sub> - PPL112 6E <sub>H</sub> - PPL110 64 <sub>H</sub> - PPL100 D2 <sub>H</sub> - PXL210 D4 <sub>H</sub> - PXL212
SW	number of SW
CRC	checksum

In the event of an error in the command is coming error message ([see error table](#)) or converter does not respond at all.

example		
description	command example	response example
identification PXL212 version SW 3	01 11 C0 2C <sub>H</sub>	01 11 02 D403 A23D <sub>H</sub>

## 7. Error table

If an error occurs after the function call will be in error response the number of function increased about 80H. In the data, followed by the error number.:

<address> <function +80<sub>H</sub>> <error number> <CRC>

error number	
01 <sub>H</sub>	unknown function
02 <sub>H</sub>	error in the number of registers
03 <sub>H</sub>	error in other data
04 <sub>H</sub>	Input is out of range (disconnected, short-circuit)

Example of an error message with the address 02<sub>H</sub> converter with input out of range when you call the function 03<sub>H</sub> is as follows:

(02 83 04 B0 F3)<sub>H</sub>

## 8. EEPROM map

To write values and addresses of the memory is used for 16-bit value written in hexadecimal.

description of meaning of addresses in the address		
memory	value	availability
0001 <sub>H</sub> a 0002 <sub>H</sub>	32b input value 1 (long integer)	only read
0003 <sub>H</sub> a 0004 <sub>H</sub>	32b input value 2 (long integer)	
0011 <sub>H</sub>	16b input value 1	
0012 <sub>H</sub>	16b input value 2	
1000 <sub>H</sub> to 1029 <sub>H</sub>	linearization data	read/write
102A <sub>H</sub>	configuration word ( <a href="#">see table 1</a> )	
102B <sub>H</sub>	correction of input 1 *)	
102C <sub>H</sub>	correction of input 2 *)	
102D <sub>H</sub>	MSB month of calibration LSB year of calibration	
1032 <sub>H</sub>	MSB communication parameters ( <a href="#">see table 2</a> ) LSB converter address	
1034 <sub>H</sub> a 1035 <sub>H</sub>	32b serial number	only read

\*) The correction value input is 16-bit hexadecimal number in supplemental form.

We can express both positive and negative shift of a given number of digits.

Shift of +1 digit number is expressed as 0x0001,

shift by -1 digit number then 0xFFFF

## 9. Table 1 - Meaning of bits in the configuration word

Bit	meaning	description
16 (MSB)	unmeaning	0
15		
14		
13		
12		
11		
10		
9		
8		
7	response to the overflow	0 - error message 1 - value about 6% out of range
6	unmeaning	0
5	filter	0 - filter OFF 1 - filter ON
4	unmeaning	0
3	Swap order of the output 32b	0 - 16b MSB then 16b LSB 1 - 16b LSB then 16b MSB
2	compensation	0 - 3W or cold junction compensation 1 - 2W or without cold junction compensation
1 (LSB)	resolution of the input	0 - 15 bits 1 - 14 bits

## 10. Table 2 - Meaning of bits in the communication word

bit	meaning	description
16 (MSB)	unmeaning	0
15		
14		
13	baud rate [Bd]	00 - 19200Bd
12		01 - 9600Bd 10 - 4800Bd 11 - 2400Bd
11	parameters (number of data bits parity number of stop bits)	1xx - 8N1 **)
10		000 - 8E1
9		001 - 8O1 01x - 8N2
8	device address (express in binary code)	number of range <1 .. 247>
7		
6		
5		
4		
3		
2		
1		

\*\* ) x - regardless of the value of the bit.